

CC852 Thermostat and Receiver Binding Guide

Step 1)

Open the Cover on the back of receiver to expose the 8 DIP Switches on the back of the unit. Move some of the switches to the down position and take note which switches are up and which are down. For example in this photo, 3, 7 and 8 are in the down position, 1,2,4,5,6 are in the up position.



If you wish one thermostat to control several receivers, please make sure that the same code is put onto all the other receivers

Step 2)

On the thermostat press and hold the PROG and Return Key simultaneously for 1 second to enter the menu.

Press the Moon key once to get to the address code. The display should show ADR and the current address.

Press return and 1 will start flashing. If number 1 in your code is up, press the Sun key. If number 1 is down, press the moon key.

2 will start flashing. Again if number 2 is up in your code press the Sun key or the moon key for down.

Repeat for all 8 switches in your code.

Press return to return to the menu.

After a few seconds, it will return to the main screen. Again press the PROG and RETURN key simultaneously to access the menu, then press the moon key to get to the address code.

The display should show ADR and the numbers in your code that are in the UP position. For our example it should show like this:



After a few seconds the thermostat will return to the main screen. Plug in the receiver, and get the thermostat to resend the signal by turning it to a low temperature, waiting 30 seconds, and turning it to a high temperature. The receiver will switch on. If it doesn't switch on, there may be interference, please start again trying a new code.