


# Ecostrad Icon iQ

## Quick Start Guide



### Scan QR Code to download the full manual



Consult the full manual for safety guidance, installation instructions, advanced settings, and warranty details.  
<https://www.electricradiatorsdirect.co.uk/manuals/ecostrad/Ecostrad-Icon-iQ-Manual.pdf>

### WARNING - READ ALL SAFETY WARNINGS AND ALL INSTRUCTIONS.

Read the provided full manual carefully before using or installing the radiator. Always store the full manual in the immediate vicinity of the radiator or its site of use.


Failure to follow the warnings and instructions may result in electric shock, fire, serious injury, or all of the above. Save all warnings and instructions for future reference.

#### Respect the minimum distances from surrounding walls, ceilings or fixed objects as stated below:


- 5 cm from the sides to masonry
- 10 cm from the sides to flammable materials
- 8 cm from the bottom to the floor
- 15 cm from the top to flammable building components or covers (e.g. wooden windowsills or shelving)
- 10 cm from the top to non-flammable building components or covers (e.g. stone windowsills)

### Control

- Use the Control screen to change the mode.
- Modes include:
  - Manual Mode
  - Program Mode
  - Boost Mode
- Adjust the heater's settings by entering the Control menu and tapping



### Display



#### Short Press

#### Long Press

- Standby Key = On/Off
- Up Key = Navigate/Increase
- Down Key = Navigate/Decrease
- Confirm Key = Select

- Standby Key = Settings Menu
- Up with Down = Child Lock
- Confirm Key = Boost

## Ecosystem App

### Installing the Application




Scan the QR code to download the Ecosystem app.

### Initial Setup

1. Create your account.
2. Navigate to the Manage Hub.
3. Press by My Heaters.
4. Select the Icon iQ from the list of available radiators.
5. Follow the instructions in the application to complete the connection.

### Set the Program (app)

1. Tap the **Program** tab on the Control interface.
2. Tap the day you wish to program.
3. Drag and drop the Eco and Comfort modes into the desired intervals.
  - Any periods left white will be set to Anti-frost mode.
4. To save your program, select **Set & Save**.
5. To copy your program to another day, select **Copy**, then tap the days that you wish to copy the program to.




# Manual Operation

## Standby Mode

In Standby Mode, the radiator will not heat\*.

1. Short press to turn off the radiator.

- \*If Frost Protection is active, the radiator will prevent the room from dropping below 7 °C.
- Frost Protection is off by default, but can be activated via the settings menu.




## Select Heating Mode

1. Short press to turn on the radiator.
2. Short press to switch between **Manual** and **Program** modes.

## Manual Mode

In Manual Mode, the radiator will heat the room to the set temperature indefinitely.

- Short press or to increase or decrease the set temperature in steps of 0.5 °C.



## Program Mode

In Program Mode, the radiator will heat the room according to the user-set program.

- Short press or to temporarily increase or decrease the set temperature in steps of 0.5 °C.
- The radiator will return to the set program at the top of the next hour




## Pre-Set Temperatures

Change the pre-set temperatures used in Program mode.

**Pre-sets:**

- Comfort
- Eco
- Anti-frost


1. Long press to enter the settings menu.
2. Select **Program**.
3. Select **Temperatures**.
4. Choose a pre-set to adjust.
5. Select a temperature.
6. Short press to save and return to the submenu.



## Boost Mode

Use Boost Mode to temporarily raise or lower the temperature for a set period of time.

1. Long press to enter the boost menu.
2. Select the boost temperature.
3. Short press to confirm.
4. Select the boost duration.
5. Short press to start boost.




Cancel the boost at any time by short pressing .

Pair the radiator to the app to automatically synchronize the radiator with the local time.

## Set Date & Time


To set the time manually, when not connected to the app:

1. Long press to enter the settings menu.
2. Select the time menu.
3. Set the day of the week.
4. Set the hour.
5. Set the minute.
6. Short press to save and return to the menu.



## Keypad Lock

- Disable all keys to prevent accidental changes.
- When active, a padlock icon will display.
- Long press or together for 5 seconds to activate or disable the keypad lock.



## Set the Program (offline)

1. Long press to enter the settings menu.
2. Select **Program**.
3. Select **Daily** (unique program for each day) or **Weekly** (one shared daily program)
  - If Daily, select which day to program.
4. On the day programming screen, short press to toggle through the temperature pre-sets.
  - The pre-set you select will be applied to the hour.
5. Short press or to move forward and backward through the hours of the day.
  - The currently selected pre-set will be applied as you navigate, unless is selected.
  - If is selected, no changes will be made as you navigate.
  - The timeline will show blue for Anti-Frost, green for Eco, and orange for Comfort.
6. Once satisfied with the daily program, short press to save the program and return to the day selection menu.
7. If desired, select another day and repeat the process to program that day.

